



T.bataar

3D

INSTRUCTION MANUAL



The design of concentrating most weight to Main Rotor to excellent 3D performance.

Main Frame composed by carbon fiber and aluminum alloy efficiently reduces resonance and leads to high shockproof quality.

Features:

- ✓ CCPM 120 degree
- ✓ 53 Precision Bearings
- ✓ Baking Varnish Fiber Glass Canopy
- ✓ 3K Carbon Fiber Main Frame with Aluminum Alloy Parts
- ✓ Variable Number of Elastic Rubber Loops in the Main Rotor Hub (from 2-8)
- ✓ Swashplate Direction-fixing Device composed of 7 bearings and 4 shaft orientations
- ✓ Vertical Movement of Flybar by a Joint composed of 12 Bearings
- ✓ Adjustable Function Inverse Proportion of Flybar
- ✓ All hand-polished Metal Parts (Not Painting)
- ✓ Beeline (Not Camber Line) Movement of the Arm of Tail Rotor Slide Bushing Device, Subtle Compensation made by an Added Shaft

Specifications:

Length: 580mm

Height: 185mm

Main Rotor Diameter: 540~600mm

Tail Rotor Diameter: 110mm

Main Shaft Diameter: 4mm

Drive Gear Ratio: 1:15:5 / 1:18:5

Weight (w/o power system): 265g (incl. Wooden Main Rotor Blade)

Weight (RTF): 466~550g

Contents

Important Notes.....	1
Assembly.....	2
Flight.....	20
Maintenance.....	23
Parts and Tools.....	25

Thank you very much for buying a SJM product. In order to be able to use this product safely, please read this manual before flying the helicopter. Please fly the helicopter safely observing all rules and manners after having fully understood the flight precautions, the unit's capabilities, and the best way to fly it. Be sure to retain the manual for future reference, routine maintenance, and tuning.

Important Notes

- This helicopter is recommended for skilled intermediates and advanced RC helicopter flyers.
- Make sure to read and follow all the instructions in this manual, including all accessories.
- Should any unclarity arise, please confirm with an experienced RC helicopter personnel / instructor before introductory flight.
- Always find an experienced and / or qualified personnel / instructor for per flight inspection.
- Make sure flight vicinity is in an open space; free of crowds, obstacles, and buildings. Failure to abide may cause accidental and potentially hazardous encounters.
- Introductory flight should incorporate only the basic maneuvers (hovering, linear ascensions and descensions), until stick feel is mastered.









Note


Fly only in safe areas, away from other people. Do not operate RC helicopters within the vicinity of homes or crowds of people. RC helicopters are prone to accidents, failures, and crashes due to a variety of reasons including, lack of maintenance, Pilot error, and radio interference. Pilots are responsible for their actions and damage or injury occurring during the operation or as of a result of RC helicopter models.

Recommended Equipment (NOT included in kit)





- Radio Control System – 6 channels or More Heli-capable transmitter and / or equivalent. (required)
- Receiver - 6 channels or more
- Gyro -1 pcs 6 g-15 g gyro
- ESC - 25 AMP or More (BEC Support 4 servos)


1

	M1.5x7CS	2
	Brg01.5x04x2ZZ	4
	Countersunk screw M2x8	2
	M2 nut	2
	M2x2SS	2
	Countersunk screw M1.6x6	5
	FW03x04.5	1
	Brg.03x06x2ZZ	2
















2

		
Countersunk screw M1.6x6		2
		
M1.6 nut		2














3


	M2 x 5CS	7
	M1.5 x 7CS	3
	Brg. ø1.5 x ø4 x 2	6
	Brg. ø2 x ø6 x 2.5F	2
	FW ø1.5 x ø2.5	3
	Linkage ball	1
	Bushing. ø1.5 x ø3 x 6.5	1
	Countersunk screw M1.6 x 6	5
	Linkage rod ø1.6 x 10	1
	Ball link H13.5	1
	Copper cap nail	1
	Servo link H17	1











4




	M1.5x7CS	6
	M2x5CS	3
	M2x2SS	12
	M3x3SS	2
	Countersunk screw M1.6x6	6
	Brg.Ø2xØ5x1.5F	2
	Linkage ball	2
	BrgØ1.5xØ4x2ZZ	12
	FWØ2.5xØ1.5	6


















6

	M2x10CS	1
	Countersunk screw M1.6x8	6
	Linkage rod M1.5x35	2
	Ball link.H13.5	2
	Ball link.H11	2
	M1.6 nut	6
	M2 nut	1
	O-Ring	8








7

 M2×10CS	4	 Brg.03×06×2.5ZZ	4
 M2×5CS	2	 Brg01.5×04×2ZZ	4
 M1.5×7CS	2	 H1fbar linkage ball	2
 M2×2SS	4	 linkage ball	4
 Countersunk screw M1.6×6	6	 Ball link H13.5	2
 Linkage rod M1.6×10	4	 FW02.5×01.5	2
 Ball link H17.5	4	 Ball link H11	4




8








		
Countersunk screw M1.6x6		7
		
Linkage ball		7




9




10











	M2-2SS	2
	Countersunk screw M1.6x5	2
	Countersunk screw M2x6	4
	M2x8CS	5
	M2x5CS	6
	Brg. Ø2x6x2.5ZZ	2
	Brg. Ø4x7x2.5ZZ	2


















11




12

		
M1.5×4CS		10
		
Brg01.5×04×2ZZ		6
		
FW02.5×01.5		6
		
Bushing.03.5×01.5×14		1
		
Bushing.03.5×01.5×9		1




 M1.5x4CS	1	 M2 Nut	1
 M1.5x5CS	4	 M2x2SS	2
 M2x6CS	8	 M2x8CS	1
 FW.05.5x04	1	 Brg. 01.5x04x2ZZ	1
 Pin 01.6x11	1	 FW.01.5x02.5	1
 linkage rod 01.6x10	2	 Bushing.02x03.5x12.5	2
 Ball link H13.5	3	 Servo link	3








When assembling the tail boom and fuselage, make sure to turn the belt 90 degrees




14














15

	Countersunk screw M1.6x5	14
	Countersunk screw M2x6	4
	M2x5CS	2
	Brg. Ø3xØ7x2ZZ	1
	One-way bearing, Ø3xØ6.5x6	1
	Brg. Ø3xØ6x2.5ZZ	2
	FW. Ø3xØ4.5	1





16

		M2x10CS	10
		M2x8CS	8
		Countersut screw M2x6	2
		M2x5CS	4
		M2 nut	12



17





Pre Flight Checks

1. As a precautionary avoidance to frequency interference (2 different helicopters utilizing the same frequency), it is important to keep the remote controllers and helicopters apart for at least a distance of 1.5 mile.
In order to prevent accidental encounters from occurring; please make sure the surrounding areas (flight area) are not populated with crowds and / or buildings (open space). Open space vicinity should be at least 100 feet in all directions.
2. Make sure the battery is completely charged. Read carefully the suggested charging time and maintenance procedures listed in the instruction manual. Attempted flight without a fully charged battery will result in an unexpected loss of power, directional control, and / or costly accidental crashes, and etc. Emptying the battery after usage will increase its connectivity.
3. You are now ready to turn ON both the transmitter (remote control) and the receiver (located on the helicopter). Make sure the helicopter is placed stably leveled on the ground before commencing. Always turn on the receiver first, prior to turning on the transmitter (remote control).
4. Test and confirm the directional controls are working properly. Try moving the directional stick and study the resulting effects of the helicopter. If no resulting movement is noticed when moving the directional stick, do not attempt flight; as either the helicopter or remote control may be defective.
5. Before test-fly, better tie the heli model to a fixed place under safe conditions, and then gradually increase its power, making it perform various movements frequently till at least one battery is used up in order to make the parts fit smoothly. After that, check the heli to see if there is any screw loose and make sure all the screw are tightly fixed.

The following lists the most recommended methods for a beginner to commence their journeys into remote control flying realm. (Listed in order of importance)

1. Find an experienced Instructor – mostly can be found at your local hobby store.
2. Join a RC club in your nearby area – can be found through the internet, hobby stores, parks, and friends (word of mouth).

3. Practicing the “Frog Jump” (will be explained later).

Never start flying without implementing any or all of the recommended methods listed above.

“Frog Jump”

1. Make sure you are standing directly behind the helicopter before any attempted flight.
2. Slowly introduce power to the helicopter in a continuous and stable pace.
3. Analyze carefully the characteristics of the helicopter. As more power is introduced, the helicopter will begin its ascension progress. Make directional adjustments to counter and insure a linear ascension and descension path.
4. Make sure never to exceed a flying height of over 2 feet! Anything over the recommended height can and may cause major damage to the helicopter if crashed.
5. Upon reaching the recommended maximum height, slowly release and let off on the throttle till landing. Always maintain the helicopter’s plane leveled to the ground.
6. Continually practice this technique until you can masterfully perform linear paths of ascension and descension, as well as stationary hovering capabilities.
7. As your skills improve, slowly introduce lateral movements to the helicopter; with your starting point of spot as the final goal (position). Make sure to keep the lateral distances within a 3 feet diameter. Furthering the recommended distance will increase accidental encounters.
8. Once these techniques are mastered, you are now ready to elevate both your helicopter and flying skills to its potential.
9. It’s strongly recommended for softened landings, slightly tilt and allow the front part of the landing strut to touch down, followed by the rear half.

Notes

Nearly 90% of crashes, for beginners, are associated with behaviors of nervousness and/or panic. Only about 10% are directly related to mechanical failures.

Repetitive practice is the only way to enhance your skill: developing controls sensitivity, awareness, and understanding.

Golden Rule of Thumb:
Practice! Practice! Practice!

Maintenance

Regular maintenance is required to keep the SJM Sparrow S-Class 3D helicopter in optimal and safe flying condition. The model requires precise configuration of the components and setting to be kept by the owner. Maintain regular maintenance on the model to avoid accidents or loss, and optimum performance.

● Main Rotor Checklist

1. Main rotor housing: When the main rotor housing is worn or faulty, there will be obvious vibration and poor flight control. Check the main rotor, main shaft, and feathering shaft for wear or deformity. Replace parts as necessary to eliminate imbalance.
2. O-rings: The O-rings will lose their elasticity over time. This will cause excess play on rotor and cause instability. Replace as needed.
3. Main rotor holder: When the heli will not fly or reacts sluggishly, even after checking for proper setting of pitch and throttle, check the following items:
▲Bearings ▲Ball bearings ▲Rotor blades ▲Other parts
4. Check for excess play or gaps between the surfaces, missing or broken parts, or binding or restricted movement, it is important to check for main rotor balance before each flight. Operating the model when out of balance will cause excessive wear and premature failure of parts, possibly resulting in a dangerous situation.
5. Control arm assembly: Check regularly for cracked, worn, bent or binding control arms and pushrods. Smooth movement of control arms and linkages is required for stable, vibration free flight.
6. Swashplate: Check for excess slop in the main ball where the main shaft rides on, and slop or looseness among all the metal parts. Swashplate wear will result in poor stability and lack of control during flight. Replace as necessary.

● Fuselage / Chassis

1. Main shaft bearing: Normal replacement interval for proper operation is between 60-100 flights. If flying 3D or extreme aerobatics often, inspect the bearing more frequently and shorten the interval as necessary.

2. One-way bearing: One-way bearings have longer lifetimes. Failure is not common. To keep the one-way bearing in good operation, remove it to clean and lubricate after every 50 flights. If the main drive gear is loose, you should replace the one-way bearing.
3. Drive belt: SJM uses only top quality, stretch-proof belts. It is however, impossible to prevent the belt from stretching or wearing out. Check belt tension regularly, and check for the wear on the teeth. Replace as necessary.

- **Linkage Rods and Connecting Parts**


During assembly, take special care to keep the connecting parts in smooth operation, and avoid excess play or binding. Failure to do so will result in poor flight stability. The linkage rods and ends will break and wear due to normal usage, crashing, and poor maintenance and environment. Check for wear and proper operation regularly, replace as needed.

- **Tail Rotor System**


1. Tail rotor control set: Check the tail rotor bearing regularly. If there is excess play or gaps replace immediately. Avoid any binding or improper contact on the tail components and bearings as this will cause excess wear and heat, potentially melting or deforming the tail system.
2. Tail unit assembly: Avoid flying in tall grass or weeds. If grass or weed becomes lodged in the tail rotor unit, it will interfere with the operation, and cause the helicopter to lose control. Always check for foreign objects in the tail and clean them off immediately. Avoid using lubricants on the exposed surfaces of the model as it will attract and collect dirt and debris, and cause failure.
3. Tail rotor housing: Disassemble tail rotor housing for cleaning and maintenance after every 50 flights. If the tail does not operate smoothly or shows any signs of stress or wear, please replace immediately.
4. Tail rotor: Check the tail rotor blades regularly for damage, especially if the helicopter ever strikes the ground while flying, or after hard landings. Damaged tail blades can induce vibration.

Notice: Maintain regular maintenance on the model to avoid accidents or loss.


OPTIONAL SPARE PARTS AND TOOLS




SJ00001




SJ10004




SJ10010




SJ10005




SJ10006




SJ10008




SJ10009




SJ10003




SJ10002




SJ10007




SJ10001




SJ30007




SJ30002




SJ30003




SP30004




SJ30005




SJ30006




SJ20001




SJ20002




SJ20003



SJ20004



SJ20005




SJ20007



SJ20006


OPTIONAL SPARE PARTS AND TOOLS



10 pcs
1.5×35mm 4pcs
1.6×10mm 6pcs

Linkage rod


SJ50003



2 types 4pcs
2×42mm 3pcs
2×21mm 1pcs

Tail rotor shaft
Belt driven shaft


SJ50002



2 pcs
1.5×210mm

Flybar rod


SJ50005



2 pcs
3×11.5mm

Feathering shaft


SJ50007



1 pc
4×109mm

Main shaft


SJ50006



10 pcs
1×11mm

Pin


SJ50001



10 pcs
H17.5mm

Ball link


SJ60004



10 pcs
H13.5mm

Ball link


SJ60003



10 pcs
H11mm

Ball link


SJ60006



10 pcs
H17mm

Servo link


SJ60005



10 pcs
H15mm

Servo link


SJ60007



10 pcs

O-Ring


SJ80009



3 pcs

Servo mount


TB0015



1 set

Carbon fiber linkage rod set

TB0002



2 set

Tail drive gear


SJ90002



2 pcs

Drive belt wheel


SJ90003



2 pcs

Flybar paddle


SJ60001



2 pcs

Tail rotor blade


SJ60002



2 pcs

Main drive gear


SJ90006



2 set

Autorotation tail drive gear


SJ90001



1 set

Canopy mounting holder


TB0006



1 pc

Drive belt


TB80005



10 pcs
M2mm

Nut

SJ70001




10 pcs
M1.6mm


Nut

SJ70002

OPTIONAL SPARE PARTS AND TOOLS




1 set Flybar set
TB0013




1 set Direction-fixing set of swashplate
TB0017



1 pc Swashplate
TB0021



1 set tail rotor angle-adjusting device
TB0007



1 set Main rotor set
TB0011



1 set Tail rotor set
TB0019



1 set Landing skid set
TB0008



1 set Tail drive gear assembly
TB0027



1 set Carbon fiber horizontal stabilizer
TB0020



1 set Tail unit housing
TB0018




1 set One-way bearing set
TB0016



2 pcs Tail servo mount
TB0009



1 pc carbon fiber vertical stabilizer
TB0004



1 pc carbon fiber tail boom
TB0003



1 set Carbon fiberboard of main frame
TB0001



1 set Main shaft stand
TB0012




1 set Main shaft fixing ring
TB0005




2pcs Wooden main rotor blade
TB80002



1 set Carbon fiberboard link
TB0010




3 pcs Tail boom holder
TB0014




1 pc Brushless motor
SJ80001



1 set Bearing stand under main shaft
TB0023




1 set Skid pipe set
TB80009




2 set Aperture 2.3mm T12 Copper motor gear
SJ90007


OPTIONAL SPARE PARTS AND TOOLS




SJ90008




SJ90009




SJ90010



TB0025




TB0026



TB0022



TB0023



SJ70003